



封底

封面

单页尺寸：115x115mm 18P
材质：105g哑粉
工艺：骑马钉

注：封面封底的背面是空白的，不要印内容

Introduction

Thank you for purchasing DEPSTECH DS430 Endoscope. Please review this user manual carefully and retain it in a safe place for future reference. If you need any assistance, please contact our support team support@depatech.com and provide your product model number and Amazon order number.

Please Note

Not following this note can cause permanent damage to the device!
Storage and transportation:
Keep the tool dry, clean, free from oil, water, gas or other materials causing corrosion. Keep work area clean and well lit. This appliance is not intended for use by persons with limited physical, sensory or mental capabilities.
This appliance is not intended for medical use or personal inspection. Keep bystanders, children away while operating the tool. Do not overreach, keep proper footing and balance at all times. Improper ways to store or transport the camera can harm the device. Always transport this device in the provided box in order to prevent damage.

DISPOSAL OF THE PRODUCT

Electronic equipment is not classified into domestic waste, but must be disposed in accordance with the applicable statutory provisions.

Specification

Battery Info	
Battery Type	Li-ion Battery
Voltage	3.7V
Capacity	2600mAh
Working Time	4h

Camera info	
Lens	2.0 MP
Resolution	1080P
Dimension	9.0mm
Horizontal View Angle	80°
Focal Range	7-40cm
LCD Screen	4.3in

Notes: TF card can be installed to achieve file storage function, supporting up to 64GB microTF card. (TF card is not included)

Product Diagram

Serial Number	Buttons and Parts Name	Operation	Function Details
1	LED Switch	Short Press	Turn on / off the LED light
2	LED Light	/	Illuminating the environment
3	Photo / Video	Short Press / Long Press	Short press to take a picture; long press to record a video, and long press it again to save the video.
4	Image Rotation	Short Press	LCD screen image clockwise rotation button, image rotation 180 degrees
5	MENU	Short Press	Enter menu options
6	OK	Short Press	Confirm / pause, play, long press to enter playback mode, press menu key to exit

7	Up	Short Press	Select the previous directory
8	Down	Short Press	Select the next directory
9	Power Button	Long Press	Long press about 1-2s to turn on or off
10	Reset	Short Press	Restart your device
11	Charging Port	/	Micro USB charging port
12	TF Card Slot	/	Support TF card max up to 64GB

Settings

After turn on the camera, press menu button to select and confirm the choice by "OK" button. Press the menu button again to exit setting.

1. Resolution Display
Take pictures of 1080P
Record videos of 720P

2. Auto-off

Set a time slot 15 min or 30 min later to turn off itself automatically.

3. Time Setting

(1) The default time setting is XXX-XX-XX. On the purpose of the video and pictures with correct time logo, please set time as your local time zone via this function. Using the button "+" "-" to choose right numbers.
(2) Exit via pressing menu button "MENU" after your setting.

4. Language Selection

(1) Go to language settings to choose via the button "+" "-".
(2) Exit via pressing menu button "MENU" after your setting.

5. Fromatting

(1) Please insert TF card when the unit is turned off. There is a icon on the screen to remind you to insert TF card.

6. Reset

(1) Activating this function will make all the settings go back to default.
(2) Exit via pressing menu button "MENU" after your setting.

Power Button Indicator Status

Indicator Status On Power Button	Charging	Breathes red
	Fully Charged	Red light solid on
	Low Power	Breathes blue
Working	Blue light solid on	

Package List

1 x Endoscope	1 x Side Mirror
1 x USB Cable 80cm	1 x User Manual
1 x Magnet	1 x Thanks Card
1 x Hook	

Note: please cautiously use this function because the files on TF card can not recover. Before formatting, please back up your profiles at first.

Charging

Input: 5V2A
Charging Way: USB connecting